

WIRELESS COATING THICKNESS TESTERS

Kett

SCIENCE OF SENSING

Model 200W, 330W



Kett

Tomorrow's Testing, Today !
1-800-438-5388

Wireless Coating Thickness Testers

The World's First Wireless Thickness Gauges!

These simple-to-use devices allow the user to conduct remote, accurate field testing of nonmagnetic coatings on both ferrous (magnetic) and nonferrous substrates. The wireless feature provides unlimited measurement flexibility. Our probes can take readings while attached to robotic or mechanized handling systems for automated measurement collection. Operators are provided with outstanding safety and the systems will provide tremendous life-spans, as troublesome cables are eliminated. For central data collection the control unit can be located in protected areas and PC-attached.

The ability to test in almost any situation opens new doors to product and process assessment. R&D personnel can easily analyze coating formulations on finished products, not just on test panels. Manufacturing personnel can measure products on the production line, improving quality assessment and production throughput.

With integrated statistical programs, data communications capabilities, and integrated printers, Kett wireless gauges provide you with years of functionality.



LE/LZ330W

Other Models

We offer a full line of gauges to meet most requirements. Please call our toll-free line to speak with a product specialist regarding your application.

When your quality is on the line, get on the line to KETT!

1-800-GET-KETT

Tomorrow's Testing, Today!

Kett offers a complete line of innovative measurement devices — for laboratory, field, and production applications. If your company needs fast, accurate measurements, please call Kett!



17853 Santiago Boulevard, Ste. 107-504
Villa Park, CA 92861
714-974-8837 • 714-974-8877 (FAX)
www.Kett.com

1-800-438-5388

Sales, Support, Service

Specifications

Model	330W	200W
Ferrous Substrates	Y	Y
Non-Ferrous Substrates	Y	Y
Range - Mils/Microns Ferrous Non-Ferrous	0-60 / 1500 0-32 / 800	0-60 / 1500 0-32 / 800
Resolution	.01mil/.1um	.01mil/.1um
Measurement Storage	1500	1500
Calibrations Stored	8	8
Accuracy +/-	.01mil (.3um) 2% (over 1.5um)	.01mil (.3um), 2% (over 1.5um)
Auto Conversion Metric/Mils	Y	Y
Alarms (Hi/Lo)	Y	Y
Printer	Optional - VZ 300	Integrated
Stats		
Lot Number	Y	Y
No. of Meas;mts.	Y	Y
Averages	Y	Y
Std. Deviations	Y	Y
Max/Min Values	Y	Y
Hi / Lo Limits	Y	Y
Power (batteries)	4 - AA	6 - AA
AC Adapter	Y	Y
Carrying Case	Leather	Leather
Calibration Standards	Y	Y
Operating Temp.	0 - 100 F	0 - 100 F
Weight - Net/Ship	1 / 3 lbs.	3 / 7 lbs.
Dimensions (mm)	30Hx75Wx140D	55Hx120Wx250D
Warranty	All Kett thickness gauges are covered by a three-year warranty on parts and labor. Post-warranty maintenance agreements are also available. Please call for information.	

Quality

We stand behind the durability and quality of our entire line of Coating Thickness Gauges. The 200W and 330W offer a full **Three-Year** warranty. We will repair or replace the product for three years should it fail to perform to specifications during normal usage.

Kett's dependable quality allows you to productively focus on improving your product's quality, not waste time calibrating and verifying your gauges.